

FORTRESS PHANTOM[®]

Gravity Metal Detector



Fortress PHANTOM Series Gravity Metal Detector

Simple
Operation

Outstanding
Reliability

Exceptional
Performance

The PHANTOM Series Advantage

The unique Fortress Phantom Gravity Metal Detector utilises the latest Digital Signal Processing technology to detect and reject ferrous and non-ferrous metals, including stainless steel. With the highest processing power, Phantom systems are renowned for their superior speed, accuracy and ease-of-use.

Applications

Flour, Rice, Cereals, Powders, Corn,
Sugar, Chemicals, Nuts

Overview

The Phantom Gravity Metal Detector is ideally suited for inline inspection of dry, powder or granular products that can be gravity fed through a pipe from a processing machine.

Available in Painted Aluminum or Stainless Steel with a selection of several aperture sizes, the Gravity detector is built with Anti-Static UHMW Pipes, Air Control, and a Ceiling Support Frame. An automatic Reject Valve can be incorporated into the system to remove contaminated product from the flow. Additionally, a test ball retrieval drawer is offered, allowing for ease of manual testing.



Key Technologies

Core DSP
Unparalleled Precision

UltraSense
Ultra Sensitive Detection

AutoTest
Self Diagnostics Testing

AutoCal
System Set-Up in Seconds

World Class Metal Detector Technology
www.fortresstechnology.co.uk

ADVANCED PHANTOM FEATURES

Core DSP	Digital Signal Processing (DSP) technology provides unparalleled precision, speed, and detection results
UltraSense	Maintains high sensitivity levels to detect the smallest metal contaminants
AutoTest	Auto Test ensures consistent performance and saves costs
AutoCal	Automatic Calibration at the touch of a button
Intuitive User Interface	Provides dedicated shortcut keys
Flash RAM	Flash Memory technology prevents information loss
Modular Design	Fewer product parts results in greater reliability

CONTROL OPTIONS

Integrated Panel	Control Panel is built into the detector
Remote Mounting	Display Panel terminal can be mounted remotely
Multiple Detector Control	One display panel can operate a number of detectors
Portable Display Terminal	Display terminal can be utilized as a portable device

GRAVITY OPTIONS

Aperture Type	Round or rectangular – standard and custom
Diverter Valve Reject System	Flap-gate or Cowbell
Floor Stands	Support frame for easy installation, ceiling or floor mount
Reject Confirmation	Confirms proper valve operation upon rejection
Test Ball Retrieval Drawer	Allows for ease of manual testing
Alarm	Audible Alarm / Visual Alarm Beacon
Air Failsafe System	Diverts system to reject on loss of power or loss of air

SPECIFICATIONS

Construction	Detector: Aluminum epoxy painted or Stainless Steel Valve: All Stainless Steel
Standard Pipe Diameters	3" / 6" / 8" (75 / 150 / 200 mm)* * custom sizes available
Rating	NEMA 4** / IP65 (HAZLOC – Class 2, Div1 & 2 available) ** upgradeable to NEMA 4X / IP69K
Remote Control Range	Up to 4000 ft / 1,200 m
Air	80 psi (4-5 bar)
Electrical	90-250v single phase, 1 amp
Communications	RS485, Optional: Ethernet / Wireless, via CONTACT Software



Make your Phantom metal detector a Critical Control Point with CONTACT Communication Software

Fortress Technology Inc.
51 Grand Marshall Dr,
Toronto, Ontario
M1B 5N6, Canada
Tel: 1-888-220-8737
sales@fortresstechnology.com

Fortress Technology Europe
7/9 Beaumont Business Ctr.
Beaumont Close, Banbury
OX16 1TN UK
Tel: +44 (0) 1295 256 266
info@fortresstechnology.co.uk

Simple Operation **Outstanding** Reliability **Exceptional** Performance

World Class Metal Detector Technology
www.fortresstechnology.co.uk